

Figure 10

- Attach lifting tackle (1) to the engine.
- Lift the engine up and pull it out towards the rear.
- Disconnect all necessary electrical cables from the following components:
 - Starter
 - Generator




Figure 11

- Unscrew screw (1).
- Unhook calmp (2) and push out rod (3).
- Lay oil cooler (4) to the side and fasten it.
- Lift out engine with radiator and engine carrier.

**WARNING!**

When opening the lid of the compensation tank (radiator cap) there is a risk of scalding because of the overpressure in the cooling system. Catch running out coolant and dispose of environmentally.

- Unscrew the drain plug, open the radiator cap and drain of all coolant. Filling quantity approx. 5 litres.
- Disconnect the water hose from the compensation container on the radiator.
- Remove top and bottom coolant hose




Figure 12

- Unscrew both screws (1) and take off the radiator grid (2).




Figure 13

- Unscrew screw (1) from both tie rods (2).




Figure 14

- Unscrew screw (1) from support (2).
- Remove screws (3) from the exhaust flange.
- Unscrew screws (4 and arrow) and take off the complete exhaust system.
- Unscrew both screws (5) of the front engine suspension.





Figure 15

- Unscrew both screws (1) of the rear engine suspension.
- Take the engine out of the engine carrier.
Weight: approx. 125 kg



E150055A

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Installing the engine | Function Group : 200 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Installing the engine

Op nbr 2101

[Lifting sling 1 m](#)
[Shackle 3/8"](#)




Figure 1

- Attach the lifting tackle to the engine. Weight approx. 125 kg.
- Place the engine into the engine carrier.
- Cover the threads of screws (1) with Loctite, turn them into the rear engine suspension and tighten with 105 Nm.




Figure 2

- Cover the threads of screws (5) with Loctite, turn them into the front engine suspension and tighten with 105 Nm.
- Assemble the exhaust system with a new seal to the exhaust manifold.
- Turn in screws (1 and 2) and tighten with 30 ± 5 Nm.
- Fasten the exhaust bracket to the engine carrier and tighten the screws (4 and arrow) with 60 ± 10 Nm.




Figure 3

- Turn in screw (1) on both tie rods and tighten with 30 ± 5 Nm.




Figure 4

- Attach the radiator grid, turn in screws (1) and tighten with 30 ± 5 Nm.
- Assemble top and bottom coolant hose with new hose clamps.
- Close the drain screw and fill in coolant.
Filling capacity: approx. 5 l
- Insert the engine with radiator and engine carrier and connect the following components:
 - Generator
 - Starter
- Push the engine forward and lower it.




Figure 5

- Turn the fastening screws (1) into the engine carrier (2) and tighten with 105 Nm.
- Remove the lifting tackle to the engine.




Figure 6

- Install oil cooler (4) and tighten screw (1) with 12 ± 2 Nm.
- Insert rod (3) and secure with clamp (2).




Figure 7

- Install hydraulic pump (1), cover the screws with Loctite, turn them in and tighten with 105 Nm.




Figure 8

- Assemble fuel tank, filter and air filter and tighten the screws (3) with 30 ± 5 Nm.
- Connect fuel line (2).
- Fasten throttle control (1) on injection pump and adjust throttle cable.





Figure 9

- Connect the breather line (1) to the hydraulic oil tank.
- Install the engine wiring loom and connect the following components:
 - Air filter contamination indicator
 - Fuel sensor
 - Glow plug
 - Shut-off solenoid
 - Plug for hand lamp
 - Temperature switch
 - Ground strap on engine and engine carrier

Fasten the cables with cable straps.


- Assemble the fastening clamps for engine cable set.



E150059A

Figure 10

- Fasten the air intake hose (2) with a new hose clamp (1) to the air intake pipe.



E150056A

Figure 11

- Assemble hood with engine hood.
- Assemble the suction hose with a new hose clamp (1).
- Bleed the fuel system.
- Connect the ground cable to the battery.
- Lift the counterweight up and fasten with the screws.
- Check engine oil level, top up if necessary
- Start the engine and make sure that there are no leaks.

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Checking the compression pressure | Function Group : 211 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Checking the compression pressure

Op nbr

[ST332270 Adapter for pressure gauge](#)




Figure 1

- Adjusting valve clearance, see [See further](#).
- Set the control lever to a position in which the fuel supply is interrupted.
- Disassemble all glow plugs and install adapter (1) ST332270 with pressure gauge (2) to one of the cylinders.
- Crank the engine with the starter.

Compression pressure, see table [See table](#)

The measured compression pressure depends on the starter speed during the measuring process and the altitude of the engine location.

Limit values can therefore not determined precisely. The compression pressure measurement is only recommended as a comparison measurement between all cylinders of an engine. If the detected deviation is higher than 10% the respective cylinder units should be dismantled to detect the cause.

- Insert all glow plugs and tighten with 17.2 ± 2.5 Nm.



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Adjusting the valves | Function Group : 214 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Adjusting the valves




Figure 1

Op nbr 21412

NOTE Clean the area around the rocker cover before starting adjustment work.

- Pull off the hose for crankcase ventilation.
- Remove the cylinder head cover.
- Crank the engine until the valves are overlapping.

NOTE Overlapping of valves means: Exhaust valve not yet closed, intake valve starts to open. In this situation both push rods cannot be turned.

Position I

| | | |
|------------|-----------------------|--------|
| Cylinder 1 | Overlapping of valves | |
| Cylinder 2 | Intake valve | adjust |
| Cylinder 3 | Exhaust valve | adjust |


Position II

Turn crankshaft one full turn (360 Grad) further in direction of engine rotation


| | | |
|------------|--------------|--------|
| Cylinder 1 | Intake valve | adjust |
|------------|--------------|--------|

Position II

| | | |
|------------|---------------|--------|
| Cylinder 1 | Exhaust valve | adjust |
| Cylinder 2 | Exhaust valve | adjust |
| Cylinder 3 | Intake valve | adjust |

**Figure 2**

- Adjust the valve clearance on the respective cylinder using a feeler gauge ([See figure](#)).
- Tighten the counter nut. Check the adjustment again with the feeler gauge.
- Attach the gasket to the rocker cover.
- Install the rocker cover. Tighten the screws with a torque of 11.3 Nm.
- Push on the crankcase ventilation hose.



E250543A



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Lubrication system, specification | Function Group : 220 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Lubrication system, specification

Specification, lubrication system

| Engine | | L3E2-64ESA |
|---|-----------|--|
| Type | | Forced feed |
| Oil | | Classification revision API CC or better |
| Capacity (max. level minus 0.5 litres of oil in filter) | | 3.6 l |
| Oil pump | Type | Gear type |
| | Driven by | Camshaft gear |
| Opening pressure of relief valve | | 3.45 ± 0,5 bar |
| Pressure difference at which the oil pressure switch is closed (warning lamp lights up) | | 0.5 ± 0.1 bar |
| Oil filter | | Paper element (full-flow) |

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Lubrication system, description | Function Group : 220 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Lubrication system, description

- The oil pump delivers pressurized engine oil to lubricate the contact faces of moving parts, such as crankshaft, camshaft, intake/exhaust valves, rockers and engine timing gears.

Schematic flow of lubrication oil





Figure 1

1. Oil pressure switch
2. Main oil gallery
3. Oil filter
4. Pressure relief valve
5. Oil pump
6. Oil drain plug
7. Oil screen



VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Removing the oil filter | Function Group : 222 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing the oil filter

Op nbr 22202


[Filter wrench](#)

Figure 1

- Place a bowl under the oil filter to catch running out oil.

**WARNING!**

Dispose of collected engine oil environmentally.

- Unscrew the oil filter from the engine block using the filter wrench.

**WARNING!**

Dispose of the disassembled oil filter environmentally.

VOLVO


Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Installing the oil filter | Function Group : 222 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Installing the oil filter

Op nbr 22202

**Figure 1**

- Slightly oil the seal on the new oil filter with engine oil.
- Screw on the new filter cartridge by hand. When the seal touches the contact face turn further for another 1/2 of a turn.

**WARNING!****Do not damage the seal during installation.**

- Fill in 0.5 litres of oil.
- Start the engine and check for leaks in the vicinity of the filter.
- Shut the engine down. Check the oil level, fill up oil if necessary.




Construction Equipment

PROSIS Service Information

| | | | |
|---|-------------------------|---|----------------------------|
| Document Title : Removing and installing the pressure relief valve | Function Group : 222 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing and installing the pressure relief valve



E250131A


Figure 1

Disassembling

Op nbr



- Unscrew the pressure relief valve (1) from the engine block.



E250144A

Figure 2

Checking the pressure relief valve

Op nbr



- Check the contact of the valve seat. Check the spring for damage.
- Measure the oil pressure (3.5 ± 0.5 bar) at which the pressure relief valve opens (oil pressure at nominal engine speed). If the pressure does not comply with the specifications unscrew the nut from the valve and increase or reduce the number of shims. The engine oil pressure connecting point is located on the right hand side of the engine.

| | | |
|------------|---|-------------------|
| More shims | = | Increase pressure |
| Less shims | = | Reduce pressure |

Installation

Op nbr



- Screw the new pressure relief valve into the engine block and tighten with 49 ± 5 Nm.



Construction Equipment

PROSIS Service Information

| | | | |
|--|-------------------------|---|----------------------------|
| Document Title : Removing the oil pressure switch | Function Group : 222 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing the oil pressure switch




Figure 1

Op nbr 22205

[Socket wrench for oil pressure switch](#)

- Unscrew oil pressure switch (1) using a socket wrench for oil pressure switch.





Figure 2

Oil pressure test

Op nbr

Ohmmeter


- Check the current flow between terminal and housing with an ohmmeter, as shown in the illustration. If this current flow is not assured replace the pressure switch.



E250136A


Figure 3
Oil pressure test (1)

- Insert a small diameter rod (1) into the oil bore of the pressure switch and push slightly in to check, whether current flow is applied (see illustration). If this is the case, replace the pressure switch.
- Blow with compressed air of 0.5 bar into the oil bore (arrow) to check whether current flow is present. If this is the case, replace the pressure switch. Check the switch also for air leaks. An air leak may be caused by a broken orifice. In this case the oil pressure switch must also be replaced.




E250147A

Figure 4
Oil pressure test (2)



E250147A



E250147A



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Installing the oil pressure switch | Function Group : 222 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Installing the oil pressure switch

Op nbr 22205

[Socket wrench for oil pressure switch](#)

- Cover the thread on the oil pressure switch with sealing compound. Turn in the oil pressure switch and tighten with the socket wrench to 10 ± 2 Nm.



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Schematic, fuel system | Function Group : 230 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Schematic, fuel system





Figure 1
Fuel system

- | | |
|--------------------|----------------|
| 1 Injection nozzle | 6 Fuel filter |
| 2 Leak oil line | 7 Fuel pump |
| 3 Injection line | 8 Fuel filter |
| 4 Injection pump | 9 To fuel tank |
| 5 From fuel tank | |



VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Bleeding the fuel system | Function Group : 230 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Bleeding the fuel system

Fuel filter with valve

Op nbr




Figure 1

**WARNING!**

Catch running out fuel and dispose of environmentally.

- Slacken bleeding screws (1 and 2).
- Start the engine, until fuel runs out of the bleeding screws without air bubbles.
- Tighten the bleeding screws.

NOTE When working on the injection nozzels, these must be bled separately.

- Loosen connections (3) on the injection lines.
- Start the engine, until fuel runs out of the injection lines without air bubbles.
- Tighten connections (3).

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|-------------------------|---|----------------------------|
| Document Title : Checking and adjusting the injection nozzles | Function Group : 230 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Checking and adjusting the injection nozzles




Figure 1
Removing the injection nozzle

1. Injection nozzle
2. Seal ring

Op nbr

[Injection nozzle tester](#)


NOTE

Ensure strict cleanliness when working on injection equipment. Use only pure testing oil acc. To ISO 4113 or clean diesel fuel to test the injection nozzle.

**WARNING!**

Keep you hands away from the nozzle yet. Fuel penetrates deep into the flesh and may cause blood poisoning.


- Remove injection nozzle with seal ring.



E250181A

Figure 2

- Attach the injection nozzle to the injection nozzle tester.
- Operate the handle of the nozzle tester with a speed of one pulse per minute in order to achieve a slow pressure increase, until the valve of the injection nozzle opens. At the moment when fluid comes out of the socket read the maximum pressure on the pressure gauge. Opening pressure with new installation: 140 ± 5 bar.



E250182A

Figure 3
Disassembling the tip of the injection nozzle

- Unscrew the spigot nut, remove all parts.




Figure 4
Sequence of individual disassembly

- 1. Spigot nut
- 2. Injection nozzle
- 3. Intermediate piece
- 4. Push rod
- 5. Pressure spring
- 6. Shims
- 7. Nozzle body

- Adjust the pressure by selecting the appropriate shim.

NOTE Increasing or reducing the shim thickness by 0.1 mm changes the injection pressure by 10 bar. 10 different shims in the thickness range from 1.25 mm to 1.70 mm in intervals of always 0.05 mm are available.

- Assemble the injection nozzle. Tighten the spigot nut with 36.8 ± 2.5 Nm. Check the injection nozzles once again with the nozzle tester.




Figure 5

E250183A

1. Injection nozzle O.K.
2. Injection nozzle not O.K.

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Checking the openings for clogging | Function Group : 230 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Checking the openings for clogging

Op nbr

[Injection nozzle tester](#)

- Watch the jet coming out of the opening. The jet must be straight.
- If the jet has any other shape dismantle the injection nozzle and clean it out. If this is not successful replace the injection nozzle.


NOTE Rework is not permitted.

Figure 1
Installing the injection nozzle

1. Injection nozzle
2. Seal ring

- Screw in the injection nozzle with a new seal ring and tighten with 54 ± 5 Nm.

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Idle speed, inspection and adjustment | Function Group : 230 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Idle speed, inspection and adjustment

Op nbr

[Tachometer](#)**For inspection:**

Normal operating temperature.

Mayor current consumption and a possible air conditioning system must be switched off.




Figure 1
Adjusting idle speed

1. Setscrew, low idle speed
2. Setscrew, high idle speed (sealed)
3. Counter nut
4. High idle speed
5. Low idle speed


Low idle speed, inspection, adjustment

- Make sure, that the control lever touches setscrew (1). Start the engine and read low idle speed.
Low idle speed: **1050 ± 100 rpm**
Turn setscrew (1) to adjust (5). After adjustment secure the setscrew with counter nut (3) and check the speed again.

High idle speed, inspection, adjustment

NOTE Adjustments on a sealed pump must only be performed in a diesel workshop authorized by Bosch.

- Check, with engine shut down and throttle pedal fully actuated, whether the control lever movement is limited by setscrew (2), see [See figure](#). Start the engine, fully kick down the throttle pedal and read high idle speed.
High idle speed, **2400 ± 20 rpm**
The adjustment (4) is made with setscrew (2), after breaking the seal.
After the adjustment secure the setscrew (2) with counter nut (3) and check the speed again.. Seal setscrew and nut.



E250231B

Figure 2
Tensioning the V-belt

1. Screw
2. Screw
3. Tightness test 10...12 mm

Tensioning the V-belt

Op nbr


⇒



WARNING!

Check/tighten or change the V-belt only with the engine stopped.

- Slacken screws (1 and 2).
- Press the generator in direction of arrow, until the correct V-belt tension is reached.
- Retighten screws (1 and 2).



E250761A

Figure 3
Changing the V-belt


1. Screw
2. Screw
3. V-belt
4. Tightness test 12 mm

Changing the V-belt

Op nbr 262106



- Slacken screws (1 and 2).
- Press the generator in opposite direction of the arrows, until the V-belt can be taken off.
- Install a new V-belt (3).
- Press the generator in direction of arrow, until the correct V-belt tension is reached.
With correct V-belt tension it should be possible to compress the V-belt with high force for approx. 12 mm (4).
- Retighten screws (1 and 2).



E150123A



Construction Equipment


PROSIS Service Information

| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Fuel injection timing | Function Group : 2331 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Fuel injection timing

General technical data

| Engine | | L3E2-64ESA |
|-----------------------------|---|--|
| Injection pump | Type | Bosch NC |
| | Designation | ND-PFR3M |
| | Piston diameter | 6.0 mm |
| | Injection delay (crank angle), degree | 8 |
| | Pressure valve, type | Silto or Bosch |
| | Bleeding screw | Yes |
| Fuel injection nozzle | Type | Throttle pin injection nozzle |
| | Designation | DN15PD6 |
| | Injection pressure (opening pressure of valve) | 140 ± 5 bar |
| Fuel filter (remote filter) | Type | Peper element |
| Fuel pump (remote pump) | Type | Electrical (diaphragm) |
| | Power (at 220 °C and a terminal voltage of 12 V DC) | 300 cm ³ /min minimum or 400 cm ³ /min maximum |



E250217A

Figure 1
Removing delivery valve and spring

1. Valve spring
2. Delivery valve

Preparation

Op nbr



NOTE When working on the fuel system ensure strict cleanliness.

- Close the valve on the fuel filter.

- Disconnect fuel injection line 1 from injection valve and injection pump.
- Remove the delivery valve holder 1 from the injection pump. Remove delivery valve (2) and holder spring (1). Install the delivery valve holder to the injection pump.
- Connect the fuel injection line to the injection pump.
- Hold the control lever in low speed position.

Inspection

Op nbr




Figure 2
Fuel running out of the injection line

Fuel outflow method

- Open the valve on the fuel filter. Turn the ignition switch to ON.



WARNING!

If the engine is fitted with an electrical fuel pump and the ignition is switched ON, fuel will run out of the injection line under high pressure. Guide the fuel jet into a suitable vessel.





Figure 3
No fuel runs out of the injection line

- Turn the crankshaft slowly in clockwise direction and keep an eye on the free end of the injection line. The moment when fuel stops coming out of the injection line is the injection timing point.

NOTE Turn the crankshaft slightly back in opposite direction and repeat the process to check the fuel injection setting.




E250220A

Figure 4
Adjustment mark

1. Reference mark
2. Mark CI

- The fuel injection setting of 17 degree (standard) is correct if the mark CI on the crankshaft pulley matches the timing gear cover at the point when fuel stops to run out of the injection line Grad.



E250221A

Figure 5
Loosening injection line 1


Alternative method

Op nbr



NOTE For the method using the outflow of fuel the delivery valve needs to be removed. Dirt may enter into the injection pump. The following method does not require the removal of the delivery valve.


- Loosen injection valve 1 in the area of the injection nozzle.
- Start the fuel circuit.
- Crank the crankshaft slowly in clockwise direction until the fuel reaches the open end of the injection line, in this moment check the position of mark CI (2) with respect to the mark on the timing gear cover (1). This setting is delayed by approx. 1 degree. This delay of 1 degree must be taken into account when choosing the shims.



E250220A

Figure 6
Adjustment mark

- 1. Reference mark
- 2. Mark CI



E250223A

Figure 7
Fuel adjustment

- 1. Shim

Adjustment

Op nbr



- If the fuel injection timing is not correctly adjusted change the thickness of the shims under the injection pump accordingly. An increase or reduction of the shim thickness by 0.1 mm changes the adjustment by 1 degree.




Figure 8
Fuel injection timing

- 1. Top dead centers
 - 2. Mark on timing gear cover
- Increase the shim thickness to delay the injection or reduce the thickness to advance the injection.

NOTE

Adjustment range ± 1.5 degree

There are four shims with a thickness of 0.2 mm, 0.3 mm, 0.4 mm and 0.8 mm available. The shims are not marked. They must be measured with a vernier caliper before installation.



WARNING!

Apply sealing compound to both sides of the shim to prevent oil leaks.

- After installation check whether the adjustment is correct.
- Close the valve on the fuel filter and return pressure valve and injection line to their original condition.

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Disassembling the fuel pump | Function Group : 2331 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Disassembling the fuel pump

Op nbr 2331





Figure 1

- Unscrew the screws from the rear counterweight, pull up the locking lever and fold the counter weight down.
- Disconnect plug connection (1).
- Disassemble fuel hoses (2).
- Unscrew both screws (3) and take fuel pump (4) off.



E150122A



Construction Equipment

PROSIS Service Information

| | | | |
|---|---------------------------------|--|-----------------------------------|
| Document Title : Installing the fuel pump | Function Group : 2331 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Installing the fuel pump

Op nbr 2331



- Fasten new fuel pump (4) with screws (3) to the frame.
- Mount fuel hoses (2) with new hose clamps.
- Join plug connection (1) together.
- Fold the counterweight up and fasten with the screws.
- Bleed the fuel system.
- Start the engine and make sure that there are no leaks.




Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------|---|----------------------------|
| Document Title : Changing the fuel filter | Function Group : 2334 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Changing the fuel filter

Op nbr 2334



E250622A

Figure 1

NOTE

Ring (2) indicates the condensation water level in the pre-filter, drain condensation water off if level is too high.

- Close fuel cock (1).



WARNING!

Catch running out fuel and dispose of environmentally.

- Slacken ring nut (3), take off and empty water separator (4).
- Take out filter (7) and spring (6).
- Check condition of seal (5), replace if necessary.




Figure 2
Fuel filter with element

Changing the fuel filter element

Op nbr 23341



- Loosen the clamps.
- Pull off fuel hoses.
- Take fuel filter element out of elastic bracket and change.



WARNING!

Dispose of fuel filter in compliance with environmental legislation.



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Technical data | Function Group : 260 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Technical data

| Engine model | | L3E2-64ESA |
|----------------------------------|--|--|
| Fan belt | | Type LL or HM (width = 10.7 mm, angle V = 38°, outer circumference = 980 mm) |
| Cooling fan | Suction fan | Number of blades = 5, Diameter = 320 mm |
| Water pump | | Centrifugal pump |
| Thermostat | Opening temperature of valve | 82 ± 1.5 °C |
| | Temperature at which the valve stroke is 8 mm | 95 °C |
| Thermoswitch | Type | Bi-metal |
| | Temperature at which the thermoswitch is set to ON | 111 ± 3.5 °C |
| | Temperature difference for SWITCHING ON/OFF | 8 ± 3.5 °C |
| Resistance in temperature sensor | | 50 °C: 80 ± 10 Ω 80 °C: 29.5 ± 2.5 Ω 120 °C: 10 ± 0.3 Ω |



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Fault remedy | Function Group : 260 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Fault remedy

General

The diagnose of anomalies, especially the ones caused by a defective injection pump, defective injection nozzles or too low compression pressure, may cause certain difficulties. It requires thorough examination, because the fault may not be caused by just one component, and it may be necessary to determine how many causes there are for this fault and which is the main reason. An anomaly can generally have several reasons.

The following pages show trouble shooting tables which will help to identify the reason for an engine fault. Each table lists the components to be tested and the testing method to be applied.

During operation diesel engines are characterized by specific features. If these characteristics are known the time needed to determine the nature of an engine problem can be reduced. The following list contains some characteristics of diesel engines which should be known to be able to perform a correct diagnose:

- Black exhaust fumes (when the engine is overloaded).
- Vibrations (caused by high compression pressure and torque).
- Irregular engine speeds (with rapid drop of engine speed).
- White exhaust fumes (with cold engine or immediately after starting the engine).

VOLVO

Construction Equipment

PROSIS Service Information


| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Removing the radiator | Function Group : 2611 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing the radiator

Op nbr 2611

**WARNING!**

Disconnect and connect the battery only with the ignition switched off. Disconnect the minus pole (green fastening) first. During assembly connect the plus pole (red cable) first.

**Figure 1**

- Disconnect the ground cable from the battery.
- Unscrew both screws (arrows) on both sides of the counterweight.
- Pull safety lever (1) and move the counterweight to bottom position.




Figure 2

- Unscrew the front socket head cap screws (1) for the hood (2).




Figure 3

- Loosen hose clamp (1) and place the suction hose (2) to the side.




Figure 4

- Unscrew both rear socket head cap screws (1) and take off hood with engine hood.




Figure 5

- Unscrew screw (1).
- Unhook calmp (2) and push out rod (3).
- Lay oil cooler (4) to the side and fasten it.

**WARNING!**

When opening the lid of the compensation tank (radiator cap) there is a risk of scalding because of the overpressure in the cooling system. Catch running out coolant and dispose of environmentally.

- Unscrew the drain plug, open the radiator cap and drain of all coolant. Filling quantity approx. 5 litres.
- Disconnect the water hose from the compensation container on the radiator.
- Remove top and bottom coolant hose




Figure 6

- Unscrew both screws (1) and take off the radiator grid (2).




Figure 7

- Unscrew screw (1) from both lateral radiator tie rods.





Figure 8

- Unscrew both nuts (1).
- Take the radiator out to the side.



E150055A

VOLVO


Construction Equipment

PROSIS Service Information


| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Assembling the radiator | Function Group : 2611 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Assembling the radiator

Op nbr 2611

**Figure 1**

- Slide the radiator (2) in from the side and turn on both nuts (1) and tighten with 60 ± 10 Nm.

**Figure 2**

- Turn in screw (1) on both tie rods at the side of the radiator and tighten with 30 ± 5 Nm.




Figure 3

- Attach the radiator grid (2), turn in screws (1) and tighten with 30 ± 5 Nm.
- Assemble top and bottom coolant hose with new hose clamps.
- Close the drain screw and fill in coolant.
Filling capacity: 5 l




Figure 4

- Install oil cooler (4) and tighten screw (1) with 12 ± 2 Nm.
- Insert rod (3) and secure with clamp (2).
- Assemble hood with engine hood.
- Assemble the suction hose (2) with a new hose clamp (1).
- Connect the ground cable to the battery.
- Lift the counterweight up and fasten with the two screws.
- Start the engine and make sure that there are no leaks.

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Removing the coolant pump | Function Group : 2621 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing the coolant pump




Figure 1

1. Screws
2. Fan
3. Intermediate pieces
4. V-belt
5. V-belt pulley

Op nbr 2621



- Hold the fan and unscrew the screws.
- Take off fan, intermediate pieces, V-belt and V-belt pulley.





Figure 2

1. Screws
2. Water pump
3. Seal

- Disconnect the hoses from the coolant pump.

NOTE Clamp the hoses with clamping pliers to prevent the coolant from running out of the hoses.

- Unscrew the screws for the coolant pump and take the coolant pump off.



E250201A

Figure 3
Checking the water pump

- Turn the shaft of the coolant pump and check for noise and smooth running, replace if necessary.




Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------|--|----------------------------|
| Document Title : Assembling the coolant pump | Function Group : 2621 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Assembling the coolant pump



E250206A


Figure 1

1. Screws
2. Water pump
3. Seal

Op nbr 2621



- Fasten the coolant pump with gasket, plate and second gasket to the engine block.
- Connect the hoses with the ports on the cooling pump.




E250209A

Figure 2

1. Screws

2. Fan
 3. Intermediate pieces
 4. V-belt
 5. V-belt pulley
- Mount intermediate pieces (3) to fan (2).
 - Attach V-belt pulley (5) to the coolant pump.
 - Fasten the fan with screws (1) to the V-belt pulley.



E250761A

Figure 3
Changing the V-belt

1. Screw
 2. Screw
 3. V-belt
 4. Tightness test 12 mm
- Assemble the coolant pump V-belt and adjust the V-belt tension.
With correct V-belt tension it should be possible to compress the V-belt with high force for approx. 12 mm (4).
 - Start the engine and make sure that there are no leaks.
 - Check the coolant level. Fill up if necessary.

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Removing the thermostat housing | Function Group : 2627 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing the thermostat housing




Figure 1
Removing the thermostat housing

1. Screw
2. Thermostat housing
3. The temperature sensor has two flags
4. The thermal switch has one flag

Op nbr



- Disconnect the hose from the cover.
- Disconnect the hoses from the thermostat housing.

NOTE **Clamp the hoses with clamping pliers to prevent the coolant from running out of the hoses.**

- Pull the electric cable off the temperature sensor.
- Remove screws (1) from the thermostat housing and take the thermostat housing off.




Figure 2
Testing the temperature sensor

- Unscrew temperature sensor ([See figure/3](#)) or thermal switch ([See figure/4](#)).
- Hang the temperature sensor ([See figure/3](#)) into a container with anti-freeze so that the sensor is below the surface of the anti-freeze and measure the resistance while heating up the anti-freeze. If the resistance does not comply with specification, see table [See further](#), replace the temperature sensor.



WARNING!

The anti-freeze in the container is very hot and can cause severe injury by scalding.





Figure 3
Testing the thermostat

- Hang the thermal switch ([See figure/4](#)) into the oil tank, so that the temperature sensor of the thermostat is below the surface of the oil and measure the resistance while heating up the oil. If the resistance does not comply with the specification (see table [See table](#)), replace the thermal switch.



WARNING!

The oil in the container is very hot and can cause severe injury by scalding.



E250198B

VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Assembling the thermostat housing | Function Group : 2627 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Assembling the thermostat housing




Figure 1

1. Cover the thread with sealing compound
2. Thermal switch or temperature sensor unit

Op nbr

- Fit the thermostat housing with a new seal to the cylinder head.
- Cover the thread of thermal switch and temperature sensor unit with sealing compound. Screw the unit in and tighten with 22.8 ± 0.4 Nm.

NOTE The thermal switch has one flag The temperature sensor unit has two flags.

- Connect the electric cable.
- Connect the hoses to the ports on the thermostat housing.
- Start the engine and make sure that there are no leaks.
- Check the coolant level. Fill up if necessary.


VOLVO

Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------|---|----------------------------|
| Document Title : Removing the thermostat | Function Group : 2627 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Removing the thermostat



E250207A

Figure 1

1. Screw
2. Cover
3. Thermostat
4. Seal
5. Thermostat housing

Op nbr 262708



- Disconnect the hose from the cover.

NOTE

Clamp the hose with clamping pliers to prevent the coolant from running out of the hoses.

- Unscrew the screws and take off the cover with thermostat and seal.




Figure 2
Testing the thermostat

- Hang the thermostat into a water container, as shown in the illustration. The thermostat must be below the water surface and should have a sufficient clearance to the side walls of the container. Heat up the water in the container evenly and measure the temperature at which the valve starts to open (82 °C). In addition measure the temperature at which the valve stroke is 8 mm (95 °C). Replace the thermostat if it is defective.



WARNING!

The water in the container is very hot and can cause severe injury by scalding.



Construction Equipment

PROSIS Service Information

| | | | |
|--|---------------------------------|--|-----------------------------------|
| Document Title : Assembling the thermostat | Function Group : 2627 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Assembling the thermostat

Op nbr 262708



- Insert the thermostat into the thermostat housing.
- Attach a new gasket to the thermostat housing.
- Assemble the cover to the thermostat housing.
- Connect the hose to the port of the cover.
- Start the engine and make sure that there are no leaks.
- Check the coolant level. Fill up if necessary.



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Electrical system, description | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Electrical system, description

The electrical system consists of three major circuits: the voltage circuit, the monitoring circuit and the control circuit.

- The functions of the main power circuit include: Starting of the engine, charging of the battery and lighting functions. The main power supply circuit works with 12 Volt.
- The monitoring circuit provides information on the operating state of the machine gathered by numerous sensors and switches.
- For easier trouble shooting all connections on wiring looms are numbered.
- Slow-blowing fuses protect the electrical components in the main power supply circuit.

Caution!

Do not disconnect electrical plug connections while the engine is running. This may cause damage to engine, I-ECU, sensors or other components.



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Electric system, trouble shooting | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Electric system, trouble shooting

Check before trouble shooting

- Malfunctions in the electric system can be identified and isolated by strictly following these worked out trouble shooting procedures. Collect all facts → Analyze the problem → Set the symptoms in relation to other systems → Examine current repairs → Use circuit diagrams → Look for the most obvious faults first → Determine and rectify the main cause.



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Basic objects of examination | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Basic objects of examination

| No. | Item | Set value | Remedy |
|-----|--|-------------|--|
| 1 | Check the battery voltage (with engine shut down). | 12 V | Replace |
| 2 | Check battery acid level. | | Use only distilled water to fill up or replace battery |
| 3 | Check for abrasion, unprotected or burned cables, damaged or disconnected plug connections. | | Replace |
| 4 | Check for missing cable terminals, loose cables, damaged connections and faulty ground cables. | | Repair |
| 5 | Look for water that runs into the cable looms. (Check thoroughly for water leaks /damaged plug connectors and pins.) Corrosion has a tremendous effect on the function of electrical components. | | Disconnect the plug connection, remove all corrosion and dry thoroughly. |
| 6 | Check the generator voltage (with engine running at a speed higher than half full speed). | 14,7 ±0.3 V | Replace |
| 7 | Abnormal noise when battery relay is operated. (Turn ignition switch ON/OFF.) | | Replace |
| 8 | Check the condition of the slow-blowing and the standard fuses (burned or discontinuous function). | | Replace |



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Diagnostics | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Diagnostics

Trouble shooting on currently used, complex electronic/electrical systems, which is based on the replacement of components according to the principle **Trial an Error** and on an unreasonable maintenance practice like the opening of wiring looms or the piercing/removal of cable insulations for test probes and multimeter clips is a **Hit or Miss method**, which is time consuming and expensive with respect to parts, labour and downtime.

Normally this results in an **temporary repair**, the rectification of a symptom, but does not eliminate the nature of the problem.

- Examine the system: Read the service manual → check the main electrical wiring diagram → become acquainted with the function of the components.
- Analyse the complaint: Ask the driver → When did the problem first occur → What is the malfunction → Were parts repaired or replaced lately → If yes, why?
- Examine the machine: Check battery, fuses, connecting pins of plug connectors, wiring looms, switches etc. → Check also other systems. E.g. no fuel
- Start the machine: Listen → Watch → Try to sense the effect of the fault symptom.
- Try to narrow down the cause of the fault: Look for the most obvious reasons first → Avoid unnecessary replacement of parts → Use appropriate tools and the correct diagrams to find the main cause.
- Objective: To isolate and identify a fault(s) on one (several) component(s).

Malfunctions in electrical control circuits, high resistance in the electrical circuit

1. A high resistance in the electrical circuit can result in weak lighting and slow or non-functioning components.
2. Fault:
 - Loose, corroded, soiled or oily connections.
 - Poor connection to ground
 - Wrong cable cross section
 - Broken flexible leads in a cable
3. To localize the fault:
 - Measure the voltage in the power circuit at various points in order to localize the section with a voltage drop, e.g. via the plug connection in a wiring loom.

Malfunctions of electrical control circuits, interrupted electrical circuits

1. An interrupted electrical circuit has the effect that no component in this circuit will work.
2. Fault:
 - Blown-out fuse, disconnected cable, plug connection without connection, loose connecting pin on a component or ground cable without connection.
3. To localize the fault:
 - Check visually for blown fuses, loose connections or cables.
 - Perform voltage tests in this electric circuit to check the continuity.
 - If there is no continuity measure along the electrical circuit, until continuity is found.

Malfunction in the electrical system, electrical circuit short to ground

1. A short to ground in an electrical circuit will cause tripping of the fuse and blow out the spare fuse after replacement.
2. Fault:
 - A conducting cable with the insulation worn off down to the unprotected conductor in contact with the chassis or a squashed cable on which the insulation has been cut open.
3. To localize the fault:
 - Check the wiring looms visually for worn or squashed sections. Pay special attention to locations where the wiring loom passes through clamps, bushings or close to hot components, such as exhaust or radiator.
 - Remove the fuse and disconnect the plug connections of the wiring loom at several places and check each location for ground connection.

Malfunction of the electrical system, short circuits

1. A short circuit in an electric circuit has the effect that components in separate electrical circuits will be actuated when switching only one of the switches in an electrical circuit.

NOTE **Components can also cause a short circuit to ground, but in such a case the fuse normally blows.**

2. Fault:
 - Two wiring looms rubbing against each other until the insulation is chafed through, so that the electrical conductors have contact between each other.
3. To localize the fault:
 - Disconnect the cable to the switch for the component that should not be active.
 - Disconnect the plug connections in the wiring loom of the electrical circuit until the component is switched off. The short circuit should be located between the two points at which the electrical circuit was interrupted.



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Precautions when handling plug connectors | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Precautions when handling plug connectors

1. Our plug connectors are fitted with an interlock. Always release the lock before disconnecting a plug connector.



Figure 1
Plug connector, precaution 1

1. When connecting align the arrows at the same level and press the parts together. Make sure that the rubber cap seals the connection properly.
2. To disconnect press this part and pull the plug connector out.
3. For connection align the guides of the plug connectors and press them together.
4. To disconnect press both ends and pull the plug connection apart.

2. Do not pull on the cables to disconnect the plug connector.




Figure 2
Plug connector, precaution 2








Figure 3
Plug connector, precaution 3

- A. Must be removed.

3. If the plug connection is hard to disconnect do not attempt to pull it out. (If it is difficult to access remove the clamp and take the wiring loom out.)







Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Identification of plug connectors/lines | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Identification of plug connectors/lines

The different parts in the electrical system are normally joined by multi-pole plug and socket connectors, enabling easy replacement of components. Lines and plug connectors are marked as follows.



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Marking of plug connectors | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Marking of plug connectors

In the wiring diagram all plug connectors are marked with their full designation.

Plug connectors between wiring looms and plug connectors on equipment have different designations:

Plug connectors for wiring looms

The designation is **CN...**, followed by a number, e.g. **CN19**.

Plug connectors on equipment

The designation is **X...**, followed by the designation of the connected equipment, e.g. **XMA3**.

XMA3 Connecting plug on X solenoid valve for slewing/offsetting (**MA3**)



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Identification of lines | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Identification of lines

In compliance with the wiring diagram all lines are identified

– in colour.



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Line connections in the wiring loom | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Line connections in the wiring loom

Each pin of a plug and socket connector has a position number ([See figure/2](#)) assigned. Beginning and end of a line have an **identical** position number.

In order to find the end of a cable, you must search for the position number assigned to the beginning of the cable in the wiring loom.

Each line is identified by a colour code ([See figure/1](#)).

Each line end is designated with the pin-no. of the connected plug ([See figure/3](#)).




Figure 1

The cable is in this case connected with the plug connection **CN7** and **CN8**. Join the wiring looms together.



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Wiring diagram - legend | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Wiring diagram - legend

Optional equipment

NOTE

Current paths for optional equipment are drawn in form of dashedlines (-----) in the wiring diagram.



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Identification of plug connectors/lines | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Identification of plug connectors/lines

The versions [See further](#) are valid.

In the wiring diagram lines are identified by colours:



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Colour codes | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Colour codes

SB = Black
R = Red
GN = Green
BL = Blue
Y = Yellow
W = White

BN = Brown
GR = Grey
P = Pink
VO = Violet
OR = Orange



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Plus connection | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Plus connection

B+ Battery (+)



Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Minus connection | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Minus connection

B- Battery (-)



Construction Equipment

PROSIS Service Information

| | | | |
|--|--------------------------------|--|-----------------------------------|
| Document Title : Designations of electrical components | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Designations of electrical components

| Designation | Designation |
|-------------|--|
| ALT | Generator |
| AUX | Accessories |
| BA | Battery |
| CA | Capacitor |
| CN | Plug connector |
| DI | Diode |
| ECU | Electronic central unit Zentraleinheit |
| FC | Fuse, cabin |
| FE | Fuse, electronic equipment |
| FH | Line fuse |
| FU | Fuse, standard equipment |
| FUSE | Fuse box, old model |
| HE | Heating element |
| IM | Instrument |
| LA | Lamps |
| LC | Control light |
| MA | Solenoid valve |
| MO | Engine |
| RS | Resistor/regulating resistor |
| BK | Switch |

Wiring diagram




Figure 1

| Designation | Designation | Comment | Page of wiring diagram |
|-------------|-----------------------------|---------|---|
| ALT | Generator | | See further , See further , See further , See further |
| AUX1 | Radio | | |
| AUX2 | Loudspeaker, left | | |
| AUX3 | Loudspeaker, right | | |
| AUX4 | Hand lamp | | See further , See further |
| BA | Battery | | See further |
| CA | Capacitor | | |
| CN1 | Cabin (ventilation/heating) | | |


| Designation | Designation | Comment | Page of wiring diagram |
|--|--|---------|---|
| CN2 | Cabin (main...) | | |
| CN3 | Headlights/boom | | |
| CN4 | Feed/boom | | |
| CN5 | Windscreen wiper, cabin | | |
| CN6 | Diagnostics (Puma)/optional immobilizer | | |
| CN7 | Pre-heater plugs, engine | | |
| CN8 | Main motor | | |
| CN9 | Unlocking of single or double acting attachments | | |
| CN10 | Pre-heating of intake air | | |
| CN11 | Main dashboard, right | | |
| CN12 | Main dashboard, left | | |
| CN13 | Input dashboard left or right | | |
| CN14 | Switch, offset/slewing and hydraulic/electric support | | |
| CN15 | Car radio (BV, AMP) | | |
| CN16 | Input wiring loom, construction site or road | | |
| CN17 | Main signal horn | | |
| CN18 | Flashing beacon between frame and beam or roll over protection structure | | |
| CN19 | Triggering of 6-way plug | | |
| CN20 | Triggering of 3-way plug | | |
| CN21 | Rear plate, ITALY | | |
| CN22 | Optional immobilizer | | |
| CN23 | Optional warning buzzer (NAFTA) | | |
| CN24 | Ground, starter relay (for optional immobilizer) | | See further |
| | | | |
| Diodes | | | |
| D11 | Fault, engine oil pressure | | |
| D12 | Fault, coolant | | |
| D13 | Battery charge condition | | |
| D14 | Interference suppression, engine fuse | | See further , See further |
| Electronic central unit Zentraleinheit | | | |
| ECU1 | Electronic multi-function switch (PUMA) | | |
| ECU2 | Basic control unit | | |
| ECU3 | Basic control unit and options | | |
| ECU4 | Control unit for engine control | | See further , See further , See further , See further |
| ECU5 | Numerical keyboard for immobilizer | | |
| ECU6 | Congtrol unit for numerical immobilizer | | |
| | | | |
| Fuses (cabin) | | | |
| FC1 | Ventilation/heating of cabin | | |
| FC2 | Memory, car radio | | |
| FC3 | Supply, car radio | | |
| FC4 | Ceiling light | | |
| FC5 | Windscreen wiper and washer | | |
| | | | |
| Fuses (electronic equipment) | | | |
| FE1 | Puma | | |
| FE2 | Puma | | |
| FE3 | Puma | | |
| FE4 | Lighting | | |
| FE5 | Cabin, optional travel alarm system | | |
| FE6 | Warning buzzer, service plug, car radio memory, optional flashing beacon | | |
| | | | |
| Main fuses | | | |

| Designation | Designation | Comment | Page of wiring diagram |
|----------------------------|---|---------|---|
| FH1 | Main fuse (MASTER) | | See further , See further , See further , See further |
| FH2 | Pre-heating plugs | | See further |
| FH3 | Pre-heating of intake air | | |
| Fuses (standard equipment) | | | |
| FU1 | Engine, dashboard, optional immobilizer | | See further , See further , See further , See further , See further |
| FU2 | Slewing/offset, hydraulic support, safe starting | | See further , See further , See further |
| FU3 | 2-speed, optional unlocking of attachments, variable track, accessories | | See further , See further , See further |
| FU4 | Lighting | | See further , See further |
| FU5 | Cabin and optional travel alarm system | | See further , See further |
| FU6 | Main signal horn, service plug, car radio memory, optional flashing beacon, immobilizer | | See further , See further , See further , See further |
| Heating elements | | | |
| HE1 | Pre-heating plugs | | See further , See further |
| HE2 | Cigarette lighter | | |
| HE3 | Pre-heating of intake air | | |
| Instruments | | | |
| IM1 | Control switch | | See further , See further , See further |
| IM2 | Hour meter | | |
| IM3 | Fuel level gauge | | |
| Lamps (illumination) | | | |
| LA1 | Headlights/boom | | See further , See further |
| LA2 | Headlight/cabin front right | | |
| LA3 | Headlight/cabin weather roof front left | | |
| LA4 | Headlight/cabin weather roof rear | | |
| LA5 | Flashing beacon | | |
| LA6 | Cabin ceiling light | | |
| LA7 | Ceiling light motor | | |
| LA8 | Headlight, front (version for construction site ED750) | | |
| LA9 | Headlight StVO, left hand side | | |
| LA10 | Headlight StVO, right hand side | | |
| LA11 | Rear plate, left hand side (ITALY) | | |
| LA12 | Rear plate, right hand side (ITALY) | | |
| LA13 | Backup light | | |
| LA14 | Direction indicator, left | | |
| LA15 | Direction indicator, right | | |
| LA16 | Parking light, left | | |
| LA17 | Parking light, right | | |
| LA18 | Brake light, left | | |
| LA19 | Brake light, right | | |

| Designation | Designation | Comment | Page of wiring diagram |
|-----------------|--|---------|---|
| Control lights | | | |
| LC1 | Headlights/boom | | See further , See further |
| LC2 | Headlights/cabin or weather roof | | See further , See further |
| LC3 | Flashing beacon | | See further , See further |
| LC4 | 2-speeds | | See further , See further |
| LC5 | Travel safety | | |
| LC6 | Pre-heating of engine | | |
| LC7 | Engine oil pressure | | |
| LC8 | Coolant temperature, engine | | |
| LC9 | Battery charge condition | | |
| LC10 | Contamination of hydraulic oil filter | | |
| LC11 | Contamination of air filter | | |
| LC12 | Serviceleuchte | | |
| LC13 | Cabin heating | | |
| LC14 | Unlocking of attachment, right hand side | | |
| LC15 | Unlocking of attachment, left hand side | | |
| LC16 | Working headlights, rear | | |
| LC17 | Slewing/offsetting | | See further |
| LC18 | Variable track | | See further , See further |
| LC19 | Hour meter | | |
| LC20 | Headlights | | |
| Solenoid valves | | | |
| MA1 | Support | | See further , See further |
| MA2 | 2-speeds | | See further , See further |
| MA3 | Slewing/offsetting | | See further , See further |
| MA4 | Variable track | | See further , See further |
| MA5 | Unlocking of attachment | | |
| MA6 | Accessory, right hand side | | |
| MA7 | Accessory, left hand side | | |
| Engines | | | |
| MO1 | Starter | | See further , See further , See further |
| MO2 | Fuel pump | | See further , See further , See further |
| MO3 | Ventilator/cabin heater | | |
| MO4 | Windscreen washing system, front | | |
| MO5 | Windscreen wiper, front | | |
| Relay | | | |
| RE1 | Starter (40) | | See further , See further , See further |
| RE2 | Pre-heating of engine | | See further , See further , See further |
| RE3 | Lighting | | See further , See further |

| Designation | Designation | Comment | Page of wiring diagram |
|-----------------|--|---------|---|
| RE4 | Engine safety | | See further , See further , See further , See further |
| RE5 | Slewing/offsetting | | See further , See further |
| RE6 | Safety with engine running | | |
| RE7 | Pre-heating delay | | See further , See further , See further |
| RE8 | Unlocking of attachment, double acting | | |
| RE9 | Steering switch-over | | |
| RE10 | Pre-heating of intake air | | |
| RE11 | Intake air pre-heating delay | | |
| RE12 | Digital immobilizer | | |
| RE13 | Safety, hydraulics | | See further , See further |
| RF1 | Direction indicator | | |
| Resistors | | | |
| RS1 | | | |
| Warning buzzer | | | |
| SA1 | Main signal | | See further , See further |
| SA2 | Travel operation | | |
| SA3 | Unlocking of attachment | | |
| SA4 | Fault, engine oil pressure | | |
| Transducer | | | |
| SE1 | Fuel level | | See further , See further |
| SE2 | Engine oil pressure | | See further , See further |
| SE3 | Thermal switch, coolant | | See further , See further |
| SE4 | Contamination of hydraulic oil filter | | |
| SE5 | Contamination of air filter | | See further , See further |
| SE6 | Transport, valve/boom | | |
| SE7 | Steering switch-over | | |
| SE8 | Hydraulic oil temperature | | |
| SE9 | Coolant temperature (sensor) | | |
| Electro magnets | | | |
| SO1 | Engine shut down | | See further , See further |
| Switch | | | |
| SW1 | Ignition switch | | See further , See further , See further , See further , See further |
| SW2 | Headlights/boom | | See further , See further , See further |
| SW3 | Headlight/cabin weather roof | | See further , See further , See further |
| SW4 | Flashing beacon | | See further , See further |

| Designation | Designation | Comment | Page of wiring diagram |
|-------------|--|---------|---|
| SW5 | 2-speeds | | See further , See further , See further |
| SW6 | 2-speeds, secondary | | See further , See further |
| SW7 | Buzzer | | See further , See further |
| SW8 | Slewing/offsetting | | See further , See further |
| SW9 | Safety of working hydraulics | | See further , See further |
| SW10 | Safety of secondary hydraulics | | See further , See further , See further |
| SW11 | Variable track | | See further |
| SW12 | Ventilation/cabin heating | | |
| SW13 | Windscreen wiper and washer | | |
| SW14 | Unlocking of attachment, right hand side | | |
| SW15 | Unlocking of attachment, left hand side | | |
| SW16 | Transport lock/boom | | |
| SW17 | Travel lever, right | | |
| SW18 | Travel lever, left | | |
| SW19 | Warning buzzer, travel system | | |
| SW20 | Equipment accessories/control lever, right | | |
| SW21 | Equipment accessories/control lever, left | | |
| SW22 | Oscillation lock | | |
| SW23 | Hazard light system | | |
| SW24 | Working headlights, rear | | |
| SW25 | Battery disconnecting switch | | |
| SW26 | Headlights, front | | |
| SW27 | Starting safety for engine, clutch pedal | | |
| SW28 | Multi-function switch | | |
| SW29 | Foot brake contact switch | | |
| SW30 | Backup light contact switch | | |
| SW31 | Hand brake contact switch | | |





Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Complete wiring diagram (part 1) | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Complete wiring diagram (part 1)





Figure 1

- 1 Switched ground from relay - RE1 (starter). (Only on version with immobilizer)





Construction Equipment

PROSIS Service Information

| | | | |
|---|--------------------------------|--|-----------------------------------|
| Document Title : Complete wiring diagram (part 2) | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |

Complete wiring diagram (part 2)






Figure 1

- 1 Switch - SW10 bridged.








Construction Equipment

PROSIS Service Information

| | | | |
|--|-------------------------|---|----------------------------|
| Document Title : Travel operation | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |


Travel operation



E150092A

Figure 1

- SW5 Selector switch, 2 speed ranges
- SW6 Switch for 2 speed ranges, secondary



E150093A

Figure 2

- MA2 2-speed solenoid valve

The solenoid valve - MA2 is located in the driver's cab under the floor plate on the left hand side.

Fuses




Figure 3

- FU3/10 A 2-speeds, attachment carrier, variable track, accessories

Travel operation




Figure 4




Construction Equipment

PROSIS Service Information

| | | | |
|--|-------------------------|---|----------------------------|
| Document Title : Travel operation | Function Group : 300 | Information Type : Service Information | Print Date : 19/10/2011 |
| Profile : CEX, EC15B XTV (Volvo) [GB] | | | |


Travel operation



E150092A

Figure 1

- SW5 Selector switch, 2 speed ranges
- SW6 Switch for 2 speed ranges, secondary



E150093A

Figure 2

- MA2 2-speed solenoid valve

The solenoid valve - MA2 is located in the driver's cab under the floor plate on the left hand side.