

Engine


Components

- | | |
|----|---------------------------------|
| 1 | Battery |
| 2 | Starter motor |
| 3 | Anti-start module |
| 5 | Anti-start module |
| 6 | Run/stop solenoid |
| 7 | Ignition switch |
| 8 | Hour-meter |
| 9 | Warning lights |
| 10 | Engine cold start warning timer |
| 11 | Glow plugs |

Relay

- | | |
|---|----|
| 4 | R2 |
|---|----|

Engine - HD850 - HD1000 - HD1200 - Mini Dumper



TV073177